

USER MANUAL

VOYAGE Mini Eye Massager



Product Introduction

With the principle of constant temperature 42 degrees and high frequency vibration, the nutritive ingredients of the skin care products are introduced into the bottom of the skin, which can be effectively penetrated.



The product is small in shape, convenient to carry, finger belly shape design, suitable for every angle of eye massage; vibration massage and thermal massage two modes, enhance eye skin, remove black eye circle, desalination pattern, eye edema, lighten eye bag.

Product Show



Product Parameters

Product Name: Mini Eye Massager	Rated power: 3W
Product model: VOYAGE	Battery capacity: 300mAh
Product Size : 120x26x26mm	Vibration frequency: 10000 times/Min
Rated voltage: 3.7V ==	Charging time :90minutes

Cleaning method

After the product is used up, wipe it clean with cloth under shutdown, then cover it with a protective cover and place it in a cool and dry place. In addition, the product is not waterproof, do not rinse with water.

Usage Method

- 1, The LED bright blue light is a vibrating massage mode, and the LED bright red light is warm and vibrant mode. The first use of the default working state is the blue light (vibration mode).
- 2, Press it once more. When the red light is on, vibration + constant temperature mode, and then shut down after 3 seconds.
- 3, In order to achieve the best use effect, it is recommended that skin care products such as eye cream can be applied around the eyes before the instrument is used, and then choose a good care mode to massage the eyes and promote absorption.
- 4, Each mode of the product is automatically switched off after 5 minutes.
- 5, The nursing mode can be switched on the basis of personal needs.
- 6, This product has an intelligent memory mode. For example, last time it was last used, it was warm + vibration mode.

Charging

The product is charged with USB charging wires. When the power is insufficient, please charge it to saturation. It takes about 90 minutes to fill it. For the first time, please charge it for about 3 hours. When charging, the head indicator lights flashing red; After filling, the indicator light turns on the blue light and does not flash.

Matters needing attention

- 1, Before using products, please read the instructions carefully and keep them for reference.
 - 2, If you feel uncomfortable or abnormal in use, stop using it immediately and consult a doctor.
 - 3, The product has no waterproof function. Do not put it in water or wash it.
 - 4, Please place products in dry and ventilated places to avoid sunlight exposure and no corrosive chemicals around.
 - 5, Care, please take a proper amount of skin care products. If excessive use of skin care products, the skin can not absorb all of the waste, while there is a residual liquid infiltration into the product of the possibility, damage the product or affect the life of the product.
 - 6, Do not let children contact or use this product, so as to avoid any danger.
- Implementation Standard GB 4706.1-2005, 4706.15-2008

Qualification Certificate

Model: _____ P/N: _____
LOT: _____ Ship Date: _____
Check Date: _____ Checker: _____



Warranty Card

Name: _____
Buy Date: _____
Phone number: _____
Address: _____
Issues: _____