
Size:425x122mm 五折页

FELINE Feet Callus Remover



English


☐ Introduction

Congratulations on your purchase!

This Callus Remover is an innovative device created to smooth dry,rough and calloused skin on the feet.unique rollers grinding spins 360 degrees, at an amazing 40 times a second,300 degrees wide angle to gently and effectively buff away hard, jagged skin on the heels. This Callus Remover works faster and is safer than metal scrapers, with no blades to cut the skin, and easier to use than other methods, that require constant rubbing to achieve results.it is Rechargeable and designed to fit comfortably in your hands.smooth,silky feet has never been easier.

This Callus Remover is recommended for one person only for hygienic reasons, unique rollers grinding should not be shared with others.

General description of parts



➡ Warning/Important

1. The Callus Remover is only for use on the feet and heels. Do not use this device anywhere eles on the body. 2.Use the Callus Remover only for purposes described in this instruction book.

3.Each head is recommended for one person only. For hygienic reason, the head should not be shared with others, 4.Do not use if you have diabetes or poor blood circulation. 5.If you have any skin conditions or other medical issues, please consult with your physician prior to use.

6.Do not use on skin for more than 2-3seconds at a time. 7.Do not use on skin that is red,iirritated inflamed, infected or blistered.

8.Do not use on warts,on sores or open wounds.. 9.Discontinue use immediately if you experience any pain or Irritation.

10. Overuse may cause skin irritation.

11.Seek medical attention if skin becomes severely irritated or bleeds.

12.Household use only.

13. This appliance is not Intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their Safety.

www.praimv.com

hello@praimy.com

How to charging

If you use this product for the first time or if it has not been used for a long time, you should charge this product continuously for more than 2 hours

PRAIMY

If it is fully charged, it can be used for about 60 minutes. The specific usage time is related to your usage habits and cleaning methods. It must be charged, used and stored at a temperature between 5 °C and 35 °C

Charge the product for 2.5 hours each time, but no more than 12 hours

1. Press the switch for 3 seconds to stop the operation of the product.

2. Hold the product with one hand, and insert the DC interface of the charging cable into the charging port of the machine (Figure 1) with the other hand. Pay attention to the same direction of tail insertion as the charging port. Remarks: when charging, the digital screen will gradually flicker, and the fully charged digital screen will display 100% of the power

How to use

This electric foot grinder is specially designed for grinding calluses and thick cutins on soles and heels. Please do not use it on other parts of your body.

1. First rinse and clean the skin of your feet, and then wipe it clean. Caution: Please do not use it on injured skin.

2. Ensure that the grinding head has been correctly installed in the machine, please refer to the part on how to disassemble the grinding head.

3. Press the switch for 3 seconds, start the machine, enter the low gear by default, and "ONE" lights up on the digital screen. Press the switch once again to enter the fast gear, and the "TWO" on the digital screen lights up.

4. Hold the machine body in hand to polish the grinding head on calluses, corns and rough skin for 2-3 seconds. Do not use excessive force, and slowly brush across the skin surface you want to polish. If you use too much force, the machine will stop working. Please stop polishing after a period of time and check whether the desired effect has been achieved. If not, repeat polishing in this area for 2-3 seconds until you get the desired effect.

Warning: If the skin feels pain or discomfort, please stop using it.

Warning: Do not polish the same position on the skin for more than 2-3 seconds.

5. Press the switch for 3 seconds to turn off the machine. 6. Rinse or wipe off the dandruff on the skin with a wet towel.

7. Clean the grinding head, please refer to the instructions on how to clean it.

8. After using this product, please install the transparent protective cover to protect the grinding head. Note: When installing the transparent cover, the " "on it is aligned with the " "on the transparent cover, and a "click" sound is heard.



Changing the Unique Roller Grinding Head

According to one's own needs or use by many people, this machine can replace different grinding heads.

1. as shown in fig. 4, put the gripper for grinding head in place , press both ends of the gripper with fingers, and pull it up at the same time, so that the grinding head can be easily removed. 2. To install the grinding head into the machine, just press the grinding head down and hear a "click", indicating that it has been installed in place.

Note: If the grinding head is not firmly installed in place, please do not start the Callus Remover.




How to Cleaning

Note: Clean the appliance after each use to ensure better performance

This Callus Remover is water resistant It can be rinsed under water for cleaning:

1. First remove the transparent cover, grinding head and dust cover.

2. Clean the dandruff and dust on the foot grinder with a cleaning brush. Please do not start the machine when cleaning.







14.Do not place or store your unit in direct sunlight.please store your unit in at a cool dry place at a temperature between 0-40°C.Keep the appliance dry, when It is not in use. 15.Do not turn your unit On if the Rollers Grinding head is not attached. 16.Do not drop or insert anything into any opening of the unit. 17.Do not use your unit outdoors. 18.Children should be supervised to ensure that they do not play with this appliance. 19.Keep your unit out of reach of children as it is not intended for use by children. 20. This appliance is not to be used on, by or near children or invalids. 21.To prevent accidents and injury to you or damage to the unit -when your Callous Remover is in use, keep it away from the hair on your scalp, your eyebrows, eyelashes as well as clothes,brushes wires,cords,shoelaces, etc. 22.Do not continually rub the unit on the same area or apply strong pressure. 23.Keep the protective cover on your unit when it is not in use. 24.Do not disassemble this device.

Attention: Do not use salt water, hot water above 60° C, thinner, gasoline, alcohol or other chemicals to clean the Callus Remover

Tips: This product is waterproof IPX6 and can be cleaned in water.

Storage

When the appliance is not in use, put it on a dry place that children can not touch.Put the cord beside the appliance properly.don't wrap the power cord around the appliance. Do not palce the appliance and the adaptor in an area with excessive heat or moisture





Correct disposal of this product

This marking (Fig.12) indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection return your used device, please use the return and collection purchased. They can take this product for environmental safe recycling.